


2b UPPER END, BEARING ON WALL

RFPI®-Joist blocking panel,
x-bracing, $\frac{23}{32}$ " APA Rated Sheathing 48/24, or
proper depth of rimboard as continuous closure.
(Validate use of x-bracing with local building code.)



Web Stiffener may
be required. See
Roseburg EWP
Design Guide or
Installation Guide.

**Continuous beveled wood
plate** required for slopes
greater than $\frac{1}{4}/12$. Code
recognized slope connectors
may be substituted. For slopes
greater than $\frac{4}{12}$ connectors are
required to resist lateral thrust.

Attach blocking panel (or
Rimboard) to top plate with
8d nails @ 6" o.c. (when used
for lateral shear transfer, nail
to bearing plate with same
nailing as required for decking)

**Uplift connections
may be required.**