


**1b RIGIDRIM® RIMBOARD**



**RIGIDRIM® Rimboard**  
(see Roseburg EWP Design Guide for design properties)

One 8d nail at top and bottom flange

**Attach RIGIDRIM® Rimboard** to top plate using 8d box toenails @ 6" o.c.  
(when used for lateral shear transfer, nail to bearing plate with same nailing as required for decking)

Attach RFPI-Joist to top plate with **one 8d nail each side** of the flange at bearing.

**To avoid splitting flange**, install nails a minimum of 1½" from end of I-joist. Nails may be driven at an angle to avoid splitting of bearing plate.

