


1a BLOCKING PANELS



RFPI® blocking panel vertical load transfer = 2000 plf maximum
-or- RigidRim Rimboard (see Roseburg EWP Design Guide for design properties)

Attach blocking panel (or Rimboard)
to top plate with 8d nails @ 6" o.c.
(when used for lateral shear transfer,
nail to bearing plate with same nailing
as required for decking)

Attach RFPI-Joist to top plate with
one 8d nail each side of the
flange at bearing.
To avoid splitting flange,
install nails a minimum of 1½"
from end of I-joist. Nails may
be driven at an angle to avoid
splitting of bearing plate.