


Roof Framing & Construction Details

Note:
See Roseburg EWP Design Guide
or Installation Guide for detail
information and installation
recommendations.



WARNING: Install temporary bracing
per *Safety and Construction Precautions*
located in the Roseburg EWP Design
Guide or Installation Guide.

Note:
Maximum roof slope
of 12/12 for details
shown herein