


**DOUBLE I-JOIST - Verify detail with EOR (For uniformly top-loaded I-joists only)**

**Block thickness should be equal to or slightly thicker than flange overhang.**



**Assembly Sequence**

- Step 1 - Nail "A" blocks to face of web on joist "Y" only. Back web during nailing to prevent damage to web flange connection.
- Step 2 - Nail "B" blocks to "A" blocks.
- Step 3 - Nail through web of joist "Z" to "B" and "A" blocks. Repeat steps 1 through 3 if more than two joists are to be joined.

