

Floor Framing & Construction Details

Some framing elements such as blocking panels have been omitted for clarity.

WARNING: Install temporary bracing per *Safety and Construction Precautions* located in the Roseburg EWP Design Guide or Installation Guide.


Note: See Roseburg EWP Design Guide or Installation Guide for detail information and installation recommendations.

Holes may be cut in web for plumbing, wiring and duct work. See charts in Roseburg EWP Design Guide or Installation Guide.

NOTE: Never cut or notch flanges.

RIGIDLAM® LVL headers

RIGIDLAM® LVL headers



NOTE: Roseburg does not require mid-span blocking or bridging in RFPI floor or roof applications

Use correct hanger for product and load. See Roseburg EWP Design Guide for more information.